SONY

[Product Information]

Ver.1.1

IMX425LLJ

Diagonal 17.6 mm (Type 1.1) CMOS solid-state Image Sensor with Square Pixel for Monochrome Cameras

Description

The IMX425LLJ is a diagonal 17.6 mm (Type 1.1) CMOS active pixel type solid-state image sensor with a square pixel array and 1.78 M effective pixels. This chip features a global shutter with variable charge-integration time. This chip operates with analog 3.3 V, digital 1.2 V, and interface 1.8 V triple power supply, and has low power consumption. High sensitivity, low dark current and low PLS characteristics are achieved. (Applications: FA cameras, ITS cameras)

Features

- CMOS active pixel type dots
- Built-in timing adjustment circuit, H/V driver and serial communication circuit
- Global shutter function
- Input frequency
 37.125 MHz / 74.25 MHz / 54 MHz
- ♦ Number of recommended recording pixels: 1604 (H) × 1100 (V) approx. 1.76 M pixels
 - Readout mode All-pixel scan mode ROI mode Vertical / Horizontal - Normal / Inverted readout mode
- Readout rate
 Maximum frame rate in

All-pixel scan mode: 8 bit: 662.1 frame/s, 10 bit: 565.1 frame/s, 12 bit: 481.4 frame/s

- ♦ 8-bit / 10-bit / 12-bit A/D converter
- CDS / PGA function
 0 dB to 24 dB: Analog Gain (0.1 dB step)
 24.1 dB to 48 dB: Analog Gain: 24 dB + Digital Gain: 0.1 dB to 24 dB (0.1 dB step)
- I/O interface
 SLVS (2 ch / 4 ch / 8 ch switching) output (594 / 297 Mbps per ch)
 SLVS EC (1 Lane / 2 Lane / 4 Lane / 8 Lane switching) output (2.376 / 1.188 Gbps per Lane)
- ◆ Recommended lens F number: 2.8 or more (Close side)
- ◆ Recommended exit pupil distance: -100 mm to -∞

Pregius

* Pregius is a trademark of Sony Corporation. The Pregius is global shutter pixel technology for active pixel-type CMOS image sensors that use Sony's low-noise CCD structure, and realizes high picture quality.

Sony reserves the right to change products and specifications without prior notice.

Sony logo is a registered trademark of Sony Corporation.

1

Device Structure

♦ CMOS image sensor			
♦ Image size	Diagonal 17.6 mm (Type 1.1)	Approx. 1.78 M pixels	All-pixel
 Total number of pixels 	1608 (H) × 1136 (V)	Approx. 1.83 M pixels	
 Number of effective pixels 	1608 (H) × 1104 (V)	Approx. 1.78 M pixels	
 Number of active pixels 	1608 (H) × 1104 (V)	Approx. 1.78 M pixels	
Number of recommended recording pixels	1604 (H) × 1100 (V)	Approx. 1.76 M pixels	All-pixel
♦ Unit cell size	9.0 µm (H) × 9.0 µm (V)		
♦ Optical black	Horizontal (H) direction: Front 0 pixel, rear 0 pixel		
	Vertical (V) direction: Front 32 pixels, rear 0 pixel		
◆ Package	226 pin LGA		

Image Sensor Characteristics

(Tj = 60 °C)

Item		Value	Remarks
Sensitivity (F8)	Тур.	4050 mV	1/30 s accumulation
Saturation signal	Min.	1001 mV	

Basic Drive Mode

Drive mode	Recommended number of recording pixels	Maximum frame rate [frame/s]	Output interface	ADC [bit]
All pixel	1604 (H) × 1100 (V)	257.5	SLVS 8 ch	0
		662.1	SLVS – EC 8 Lane	8
		213.5	SLVS 8 ch	12
	approx. 1.76 M pixels	565.1	SLVS – EC 8 Lane	
		180.6	SLVS 8 ch	
		481.4	SLVS – EC 8 Lane	

SONY

[Product Information]

Ver.1.1

IMX425LQJ

Diagonal 17.6 mm (Type 1.1) CMOS solid-state Image Sensor with Square Pixel for Color Cameras

Description

The IMX425LQJ is a diagonal 17.6 mm (Type 1.1) CMOS active pixel type solid-state image sensor with a square pixel array and 1.78 M effective pixels. This chip features a global shutter with variable charge-integration time. This chip operates with analog 3.3 V, digital 1.2 V, and interface 1.8 V triple power supply, and has low power consumption. High sensitivity, low dark current and low PLS characteristics are achieved. (Applications: FA cameras, ITS cameras)

Features

- CMOS active pixel type dots
- Built-in timing adjustment circuit, H/V driver and serial communication circuit
- Global shutter function
- Input frequency
 37.125 MHz / 74.25 MHz / 54 MHz
- ♦ Number of recommended recording pixels: 1604 (H) × 1100 (V) approx. 1.76 M pixels
 - Readout mode All-pixel scan mode ROI mode Vertical / Horizontal - Normal / Inverted readout mode
- Readout rate
 Maximum frame rate in

All-pixel scan mode: 8 bit: 662.1 frame/s, 10 bit: 565.1 frame/s, 12 bit: 481.4 frame/s

- 8-bit / 10-bit / 12-bit A/D converter
- CDS / PGA function
 0 dB to 24 dB: Analog Gain (0.1 dB step)
 24.1 dB to 48 dB: Analog Gain: 24 dB + Digital Gain: 0.1 dB to 24 dB (0.1 dB step)
- I/O interface
 SLVS (2 ch / 4 ch / 8 ch switching) output (594 / 297 Mbps per ch)
 SLVS EC (1 Lane / 2 Lane / 4 Lane / 8 Lane switching) output (2.376 / 1.188 Gbps per Lane)
- ◆ Recommended lens F number: 2.8 or more (Close side)
- ◆ Recommended exit pupil distance: -100 mm to -∞

Pregius

* Pregius is a trademark of Sony Corporation. The Pregius is global shutter pixel technology for active pixel-type CMOS image sensors that use Sony's low-noise CCD structure, and realizes high picture quality.

Sony reserves the right to change products and specifications without prior notice.

Sony logo is a registered trademark of Sony Corporation.

1

Device Structure

♦ CMOS image sensor			
♦ Image size	Diagonal 17.6 mm (Type 1.1)	Approx. 1.78 M pixels	All-pixel
 Total number of pixels 	1608 (H) × 1136 (V)	Approx. 1.83 M pixels	
Number of effective pixels	1608 (H) × 1104 (V)	Approx. 1.78 M pixels	
Number of active pixels	1608 (H) × 1104 (V)	Approx. 1.78 M pixels	
Number of recommended recording pixels	1604 (H) × 1100 (V)	Approx. 1.76 M pixels	All-pixel
♦ Unit cell size	9.0 μm (H) × 9.0 μm (V)		
♦ Optical black	Horizontal (H) direction: Front 0 pixel, rear 0 pixel		
	Vertical (V) direction: Front 32 pixels, rear 0 pixel		
♦ Package	226 pin LGA		

Image Sensor Characteristics

(Tj = 60 °C)

Item		Value	Remarks
Sensitivity (F5.6)	Тур.	4910 mV	1/30 s accumulation
Saturation signal	Min.	1001 mV	

Basic Drive Mode

Drive mode	Recommended number of recording pixels	Maximum frame rate [frame/s]	Output interface	ADC [bit]
All pixel	1604 (H) × 1100 (V)	257.5	SLVS 8 ch	0
		662.1	SLVS – EC 8 Lane	8
		213.5	SLVS 8 ch	12
	approx. 1.76 M pixels	565.1	SLVS – EC 8 Lane	
		180.6	SLVS 8 ch	
		481.4	SLVS – EC 8 Lane	