

SPECIFICATION SHEET

OS II

The OS II HD is a compact camera offering crisp, HD images in buffered or streaming mode. With its flexible design, OStreaming cameras can connect to a host PC via the 10Gbps ethernet interface or to XStream camera infrastructure via the XStreamLink interface. The HD model comes standard with a Motorized MFT mount and supports up to 1920 x 1080 resolution at 5,850 fps in buffered mode. For high-G applications, the camera can be configured with an optional C mount. Additional connectivity options offer easy out-of-the box implementation for single or multi-camera installations.

- Compact form factor
- Flexible buffer or streaming options
- Motorized MFT Standard

APPLICATIONS

Automotive, Research

KEY FEATURES

Maximum Resolution	1920 x 1080
Maximum FPS @ Maximum Res	5,850 fps
Operating Temperature	-40+50°C / -40+122°F
FRAME PROPERTIES	

I MAPIE I MOI EMILES	
Sensor Type	CMOS - Proprietary
Sensor Size	17.5 x 9.85 mm
Sensor Format	1.3 inch
Pixel Size (micron)	9.13 x 9.13 μm
Pixel Depth	12 bit mono 36 bit color
Sensitivity	30,000 ISO Mono, 10,000 ISO Color
Min. Exposure Time	1µs (*Shorter integration optional)
Array	2.0 megapixel
Quantum Efficiency	50%

MECHANICAL

Weight	0.4 kg or 0.9 lbs
Dimensions	72 x 64 x 85 mm (W x H x L)
Shock & Vibration	Shock: 200G / Vibration: 40G - All axes
Mount	Motorized MFT Mount (Standard), C Mount

TRIGGERING AND SYNCHRONIZATION

Sync In	Phase-lock TTL, IEEE1588 UDP, 1PPS
Sync Out	Frame sync / Strobe
Trigger	TTL & Switch/Circular buffer with on-camera or software trigger

Model OS II-HD



POWER

Input Voltage	7-14VDC	
COMMUNICATION INTERFACE		
Ethernet	10 Gbps	
EMBEDDED LOGIC		
Debayering	Color Cameras Only	
Temporal Noise Reduction	Standard	
Dynamic Noise Reduction	Standard	
User defined ROI's and LUT's	Standard	
Frame to frame Auto-Exposure and	Standard	

SOFTWARE

Motion Trigger

Motion Studio	Windows 32/64
Motion Inspector	Windows 32/64 - MAC OS X - Apple iOS
Plug-ins/SDK	LabVIEW™ or MatLab®
File Formats	Proprietary RAW
On-the-fly Conversion	TIF, BMP, JPG, PNG, AVI, MPG, TP2, MOV, MRF, MCF

idtvision.com info@idtvision.com