


**SMALL, HIGH PERFORMANCE
UNCOOLED THERMAL MODULE**



XTM+ 640 Series

Long-wave infrared (LWIR) uncooled module with 640 x 480 resolution



*SMALL, HIGH PERFORMANCE
UNCOOLED THERMAL MODULE*

KEY FEATURES

- ◆ Compact size
- ◆ Easy connectivity via multiple interfaces
- ◆ Frame rates up to 60 Hz
- ◆ Lower detector NETD options (< 30 mK available upon request)
- ◆ Suitable for thermal security, vision enhancement and border security applications.


The XTM+ 640 Series is based on an uncooled microbolometer detector with a 640 x 480 pixel resolution.

The XTM+ 640 offers frame rates up to 60 Hz and lower detector NETD options (< 30 mK available upon request).

The modules come with either a CameraLink, GigE Vision or QTE Samtec interface and feature low weight and power.

XTM+ 640 Series

EU based supplier



KEY PERFORMANCES

Image format/Pixel pitch	640 x 480 pixels / 17 μ m
Integration type	Rolling Shutter
Spectral range	8 - 14 μ m
Max frame rate (full frame)	60 Hz or 9 Hz (CL; GigE; 16 bit DV)
Power consumption	2.9 W (CL); 4.6 W (GigE); 2.7 W (16 bit DV)
Power supply voltage	DC 12 V (CL); DC 12 V or PoE (Power over Ethernet)(GigE); DC 3.3 V (16 bit DV)

FUNCTIONS & INTERFACES

Digital output format	CL; GigE; 16bit DV
Ambient operating temperature range	From -40 °C to +60 °C
Storage temperature	From -45 °C to +85 °C
Detector NETD	<50 mK (at 30Hz, 300K, F/1); <30 mK (available upon request)
Shock / Vibration	40 g, 11 ms, MIL-STD810G, MIL-STD883J / 5 g (20 to 2000 Hz), MIL-STD810G, MIL-STD883J

PRODUCT SELECTOR GUIDE

XEN-000637 (XTM+ 640 GigE)	XEN-000642 (XTM+ 640 GigE [9 Hz])
XEN-000638 (XTM+ 640 CL)	XEN-000643 (XTM+ 640 CL [9 Hz])
XEN-000635 (XTM+ 640 16bit DV)	XEN-000640 (XTM+ 640 16bit DV [9 Hz])

sales@xenics.com



xenics.com

Xenics
Photonis Group

© Xenics. XDS019. The information furnished is believed to be accurate and reliable, but is not guaranteed and is subject to change without notice. No liability is assumed by Xenics for its use. Performance data represents typical characteristics as individual product performance may vary. Customers should verify that they have the most current Xenics product information before placing orders. No claims or warranties are made as to the application of Xenics products. Texts and pictures may not be considered as contractually binding. This document may not be reproduced, in whole or in part, without the prior written consent of Xenics.